

Список запасных частей шлифовального станка JSG-69

Index No.	Part No.	Номер детали	Описание	Размер	Q'ty
1	GB80	Socket Set Screw	M5x6	2	
2	JSG69-002	Collar		2	
3	JSG69-003	Rubber Bushing		2	
4	GB/T894.1	Retaining Ring	12	2	
5	GB/T276	Ball Bearing	6201-RS	2	
6	GB889.1	Hex Lock Nut	M6	1	
7	JSG69-007	Idler Drum Shaft		1	
8	JSG69-008	Idler Drum		1	
9	JSG69-009	Stud		1	
10	JSG69-010	Thumb Nut		1	
11	JSG69-011	Idler Drum Bracket		1	
12	JSG69-012	Spring		1	
13	JSG69-013	Platen		1	
14	JSG69-014	Belt Tension Lever		1	
15	JSG69-015	Hex Head Bolt		1	
16	JSG69-016	Abrasive Belt		1	
17	GB80	Socket Set Screw	M8x6	1	
18	JSG69-018	Bumper		1	
19	JSG69-019	Rod		1	
23	JSG69-023	Pivot Bracket		1	
24	JSG69-024	Socket Set Screw	M8x10	4	
25	JSG69-025	Anger Pointer		1	
26	GB818	Pan Head Screw	M5x8	1	
27	GB70.1	Socket Head Cap Screw	M8x28	1	
28	GB/T879	Spring Pin	6x15	1	
29	JSG69-029	Pivot Limmit Plate		1	
30	GB95-1999	Flat Washer	6mm	3	
31	GB93-1998	Lock Washer	6mm	3	
32	GB/T2676	Socket Pan Head Screw	M6x12	3	
33	GB93	Lock Washer	8mm	4	
34	GB70.1	Socket Head Screw	M8x20	4	
35	JSG69-035	Drive Drum		1	
36	JSG69-036	Set Screw	M8x10	2	
37	JSG69-037	Belt Dust Chute		1	
38	GB95	Flat Washer	5mm	2	
39	GB818	Pan Head Screw	M5x10	2	
41	JSG69-041	Belt Work Table		1	
42	GB/T879	Spring Pin	4x10	2	
43	JSG69-043	Angle Guide Plate		1	
46	JSG69-046	Lock Handle		1	
47	JSG69-047	Flat Washer	Φ8xΦ24x2	1	
48	JSG69-048	Capacitor Clamp		1	
49	GB818	Pan Head Screw	M5x8	1	
50	JSG69-050	Capacitor		1	
51	JSG69-051	Motor Assembly		1	
52	JSG69-052	Key	5x5X25	1	
53	JSG69-053	Disc Guard		1	
54	GB95	Flat Washer	6mm	3	
55	GB93	Lock Washer	6mm	3	
56	GB/T2676	Socket Pan Head Screw	M6x12	3	
57	GB818	Set Screw	M8x10	1	
58	JSG69-058	Aluminum Disc		1	
59	JSG69-059	Abrasive Disc		1	

Список запасных частей шлифовального станка JSG-69

Index No.	Номер детали	Описание	Размер	Q'ty
60	JSG69-060	Disc Dust Chute		1
61	GB95	Flat Washer	5mm	2
62	GB818	Pan Head Screw	M5x10	2
63	GB70.3	Flat Head Screw	M6x15	4
64	JSG69-064	Lock Handle		2
65	GB95	Flat Washer	φ10xφ20x2	2
66	JSG69-066	Right Trunnion		1
67	JSG69-067	Disc Table		1
68	JSG69-068	Left Trunnion		1
69	JSG69-069	Miter Gauge		1
70	JSG69-070	Power Cord		1
71	JSG69-071	Strain Relief		1
72	GB818	Pan Head Screw	M5x10	2
73	JSG69-073	Strain Relief Plate		1
74	GB95	Flat Washer	6mm	4
75	GB93	Lock Washer	6mm	4
76	GB6170	Hex Nut	M6	4
77	JSG69-77	Base		1
78	GB862.2	Serriated Washer	5mm	1
79	GB818	Pan Head Screw	M5x8	1
80	GB818	Pan Head Screw	M5x8	4
81	JSG69-81	Base Cover		1
82	JSG69-82	Switch Plate		1
83	JSG69-83	Switch		1
84	GB818	Pan Head Screw	M5x10	2
85	JSG69-85	Foot		4
86	JSG69-086	Leg		4
87	JSG69-087	Brace		4
88	JSG69-088	Top Frame		4
89	GB/T12	Carriage Bolt	M8X16	24
90	GB/T6170	Washer Head Hex Nut	M8	28
91	GB5780	Hex Head Bolt	M8X45	4
92	GB95	Flat Washer	8mm	8
93	GB/T6170	Hex nut	M8	4
	JSG69-WL	JET Warning Label (Not shown)		1
	JSG69-ID	JET ID Label (Not shown)		1
	JSG69-ML	JET Motor Label (Not shown)		1
	JET-LOGO	JET Logo with Adhesive (Not shown)		1
	JET Model Logo	JET Model Logo with Adhesive		1

Электрическая схема шлифовального станка JSG-69

	colour of strands	Litzenfarben	couleur des cordons
--	-------------------	--------------	---------------------

BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschutzschalter	déclencheur surcharge
L	machine lamp	Maschinenleuchte	lampe
LS	limit switch	Positionsendschalter	micro

JR012..... ~ 230V, 50Hz

